



LEGEND

— Limit of flood due to dam failure with the pool at spillway crest, elevation 1,060 feet NGVD.

— Average overbank depth at cross section.

— Cross Section

2000 0 2000 4000 6000
SCALE IN FEET

Contour Interval 20 and 40 feet

National Geodetic vertical datum of 1929

Source of base map: U. S. Geological Survey

7.5 minute series

NOTE: The inundated areas shown on this map reflect events of an extremely remote nature. These results are not in any way intended to reflect upon the integrity of the Hansen Dam.

U. S. ARMY ENGINEER DISTRICT, LOS ANGELES
CORPS OF ENGINEERS
LOS ANGELES, CALIFORNIA

**HANSEN DAM
EMERGENCY PLAN
INUNDATION MAPS**