



VICINITY MAP

SCALE 0 1 2 3 4 5 MILES



LEGEND

Limit of flood due to dam failure with the post of spillway crest, elevation 1,060 feet NGVD.

Average overbank depth at cross sections.

Cross Sections

SCALE IN FEET
 0 2000 4000 6000

Contour interval 20 and 40 feet
 National Geodetic vertical datum of 1929
 Source of base map: U. S. Geological Survey
 7.5 minute series

NOTE: The inundated areas shown on this map reflect events of an extremely remote nature. These results are not in any way intended to reflect upon the integrity of the Hanzen Dam.

U. S. ARMY ENGINEER DISTRICT, LOS ANGELES
 CORPS OF ENGINEERS
 LOS ANGELES, CALIFORNIA

**HANZEN DAM
 EMERGENCY PLAN
 INUNDATION MAPS**